TOTO

使用说明书 Instructions for operation

使用产品前请仔细阅读本使用说明书,并保留备用。 Before using product, read these Instructions for operation carefully and retain it for future reference.

TOTO

OG376RY 2017.10

明细单

目录

目	录·····	1
明细	单······	2-3
使用	条件与使用上的注意	4
使用	上的注意和保养	5
产品	示意图······	6
拆卸	与检查······	7-9
产品	保修卡	10
合格	·证······	11

明细单

水嘴主仰	本1套
平板拉	汗1个
反冲杠机	汗1个
排水金具	具1套
施工说問	月书······1本
使用说明	月书······1本
使用此明约	田单的产品包括:
DL367	铜合金台式单柄双控洗面器水嘴(含排水配件)
DL367#PG	铜合金台式单柄双控洗面器水嘴(含排水配件)
DL367-1	铜合金台式单柄双控洗面器水嘴(含排水配件)

明细单

DL367-1#PG 铜合金台式单柄双控洗面器水嘴(含排水配件)

DL367-2 铜合金台式单柄双控洗面器水嘴(含排水配件)

DL367-2#PG 铜合金台式单柄双控洗面器水嘴(含排水配件)

DL368 铜合金台式单柄双控洗面器水嘴(含排水配件)

DL368-1 铜合金台式单柄双控洗面器水嘴(含排水配件)

DL368-2 铜合金台式单柄双控洗面器水嘴(含排水配件)

使用条件与使用上的注意

使 用 条 件

1. 供冷水*热水压力:

最低压力 ·········· 0.05 MPa (流动压)

最高压力 ·······1.0MPa (静压)

- 2. 供水温度在4℃~90℃,建议使用热水温度60±5℃,供热水请勿使用蒸汽。
- 3. 使用环境温度0℃以上。如果低于0℃,水嘴会出现变形、冻裂等现象。
- 4. 长时间不使用时,可能导致水嘴内部及外部锈蚀不能使用等现象。
- 5. 如果您需要废弃本产品,请勿将其作为一般生活垃圾处理,请依照法规经由独立的回收体系进行合适的处理、恢复和回收。
- 6. 本说明书中的产品具有清洗功能。

使 用 上 的 注 意

▲ 警告表示如果无视此标志而误操作时,有可能造成人员重伤或死亡。★ 注意表示如果无视此标志而误操作时,有可能造成人身伤害或财产损失。

⚠警告

- 1. 幼儿禁止使用或幼儿需要由成年人监护使用、老人和残障人士等特殊 群体应在有行动能力人员陪同下使用。
- 2. 水嘴的供热水一侧处于高温状态,请注意勿使皮肤直接接触五金配件 表面,否则可能会烫伤。
- 3. 供热水请勿使用蒸汽,否则可能会烫伤。
- 4. 请勿配反冷*热水配管,否则可能会烫伤。
- 5. 如果客户不使用我司水嘴自带的进水口过滤网,可能会出现阀芯因异物进入而导致的漏水或破损的风险。

使用上的注意和保养

▲ 注意


- 1. 由于陶瓷阀芯是较精密的部件,请勿擅自分解,否则可能会造成漏水 等不良。
- 2. 请勿撞击本产品,否则可能会造成故障、漏水。
- 3. 必须使用中性洗涤剂清洗,中性以外的洗涤剂会破坏镀层或使表面变色。
- 4. 不得使用酸性洗涤剂和去污粉、抛光粉等含粗颗粒的洗涤剂和尼龙刷, 否则可能会破坏镀层等。
- 5. 可使用软布擦拭,间或用机油或车用蜡浸布擦拭,但请勿接触树脂部件,否则可能失去光泽和产生锈蚀。
- 6. 建议不要长时间不使用,否则可能会导致水嘴内部以及外部锈蚀不能 使用等现象。
- 7. 如果吐水压力大,请调节止水阀达到需要的流量,避免水势过大,溅出洗面盆。
- 8. 随着产品式样的不断更新,实物存在与图示不符的情况,但基本安装、 使用原理相同。
- 9. 由于说明书共通使用,已有产品型号可能不在说明书中体现,但安装、 使用原理相同。

保养

为长期保持产品的美观,请用户按以下方法维护保养。

- 1. 经常用软布擦拭,间或用软布蘸水擦拭。
- 2. 当有污垢且比较明显时,请用中性洗涤剂擦拭后充分进行水洗。

产品示意图



拆卸与检查

DL367

现 象	检查项目
水流量小	6、8、9
漏水	2、3、4、5、10、11
手柄晃动	1, 2
主体晃动	7
安装后万一出现故障,请按以下要 需要拆卸的情况下,请联络售后服	
小螺丝 (1. 是否充分拧紧?)	-手柄 -装饰盖
阀门压 (2. 是否充分拧紧?) 橡皮圈	- <u>0型圏</u> -接手 - 阀芯
(3. 有无划伤、脏物?) 阀之	套
(4. 有无划伤、脏物?)	累丝 0型圈 (11. 有无划伤?)
主体 吐水口 (5. 橡胶垫片有无划伤、脏物 ♣	######################################
6. 滤网是否有堵塞?) 六角螺母 (7. 是否充分拧紧?)	
耐压软(8. 是否弯	折?)
过滤网 (9. 过滤网是否有堵塞 10. 垫片有无划伤?)	
▲注意:不同示例产品的拆卸与检	查原理基本相同。


拆卸与检查


DL368

DE000		
现 象	检查项目	
水流量小	7、11、12	
漏水	2, 3, 4, 5, 6, 10, 13	
手柄晃动	1, 2	
主体晃动	9	
安装后万一出现故障,请按以下要需要拆卸的情况下,请联络售后服	务人员进行拆卸)	
表示盖小螺丝	手柄 装饰盖 接手	
(1. 是否充分拧紧?) 阀门压	·阀芯 橡皮圈	
(2. 是否充分拧紧?)	(5. 有无划伤、脏物?)	
0型圈/ (3. 有无划伤、脏物?) 0型圈/	0型圈 (4. 有无划伤、脏物?) 阀芯套	
(6. 有无划伤、脏物?)	底座	
主体	螺钉	
性水口 (7. 橡胶垫片有无划伤、脏物 8. 虑网是否有堵塞?) ✓	—主体底座 L368-1, DL368-2无底座)	
	0型圈 (2) (2) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4	
耐压软管 (11. 是否弯折?)		
过滤网 (12. 过滤网是否有堵塞? 13. 垫片有无划伤?)	الل سه سه	
▲注意:不同示例产品的拆卸与检查原理基本相同。		

拆卸与检查

不同示例手柄拆卸要领





▲注意:不同示例产品的拆卸与检查原理基本相同。

产品保修卡

用户	
销售安装店	
购买日	
保修期	自购买日起主体及阀芯保修有效期5年, 其余部件保修期为1年

- * 若上栏内容未记全,该产品保修卡将视为无效。因此请用户购买时对记入内容进行确认。
- *本产品保修卡中的保修项目仅限于产品保修卡中所约束的免费维修项目进行维修。
- * 在保修期间,若产品发生故障(漏水、渗漏),请用户向销售店或安装店出示产品保修卡及购买发票、提出修理要求。

免费维修规定

- 1. 保修期间,在用户正确按说明书、不干贴等指示,使用本公司产品的情况下,本公司将对有故障产品进行免费维修。
- 2. 在保修期内发生损坏需得到免费修理时,请持本产品保修卡和购买发票委托安装店或销售店办理。
- 3. 在保期内,下面所列场合的维修为有偿维修。
 - ①使用不当或私自进行的不当修理及改造所造成的故障及损伤。
 - ②安装施工时的不注意或过失造成的故障及损伤。
 - ③安装后又拆移等原因造成的故障及损伤。
 - ④超出使用范围以外的场合下使用本产品所造成的故障及损伤(如家庭用商品作为业务上商品使用。)
 - ⑤砂粒或污物等造成的损伤。
 - ⑥由于日常的维护保养不当造成的肮脏、电镀部分生锈等不良。
 - ⑦由于火灾、地震、水灾、雷击及其他天灾、公害、气害(液化气)、盐害及异常电压、使用指定外的电源(电压、频率)等原因造成的故障及损伤。
 - ⑧本产品保修卡没指定的场合。
 - ⑨本产品保修卡中用户姓名、销售店、安装店、购买日期未填写的场合。
 - ⑩不能出示购买发票的场合。
- 4. 本产品保修卡仅适用于中国国内。
- 5. 本产品保修卡丢失不补,请顾客妥善保管。

合格证

本品经检查判定合格

执行标准: GB 18145-2014、GB 25501-2010

产品型号: 见包装箱上的标签

产品名称: 见包装箱上的标签

生产日期:见包装箱上的标签

组装工厂: 东陶(大连)有限公司

电 话: (0411) 87624383

厂 址: 大连经济技术开发区东北二街17号

东陶(中国)有限公司

全国售后服务电话: 800-820-9787(固定电话)

400-820-9787(手机用户)

销售商: 东陶(中国)有限公司

地 址:北京市朝阳区光华路1号北京嘉里中心北楼1915室

网址: www.toto.com.cn

Contents

Contents

Contents 1
Detailed list ······ 2-3
Service conditions and attentions in use ··· 4
Attentions in use and maintenance 5
Product schematic diagram ····· 6
Dismantle and inspection · · · · · 7-9
Product Warranty Card ······ 10
Conformity Certificate 11

Detailed list

Detailed list

Main body of water nozzle ······1 set
Flat plate drawbar······1 piece
Kickback lever ······1 piece
Water drainage fittings······1 set
Instructions for construction······1 copy
Instructions for operation······1 copy

The products using this detailed list include:

DL367 copper alloy desk type single-handle doule-control wash basin water faucet.(including water drainage accessories)

DL367#PG copper alloy desk type single-handle doule-control wash basin

water faucet.(including water drainage accessories)

DL367-1 copper alloy desk type single-handle doule-control wash basin

water faucet.(including water drainage accessories)

Detailed list

DL367-1#PG	copper alloy desk type single-handle doule-control wash basin water faucet.(including water drainage accessories)
DL367-2	copper alloy desk type single-handle doule-control wash basin water faucet.(including water drainage accessories)
DL367-2#PG	copper alloy desk type single-handle doule-control wash basin water faucet.(including water drainage accessories)
DL368	copper alloy desk type single-handle doule-control wash basin water faucet.(including water drainage accessories)
DL368-1	copper alloy desk type single-handle doule-control wash basin water faucet.(including water drainage accessories)
DL368-2	copper alloy desk type single-handle doule-control wash basin water faucet.(including water drainage accessories)

Service conditions and attentions in use

Use condition

- 1. Cold water supply*hot water supply pressure Minimum pressure 0.05MPa (flow pressure) Maximum pressure 1.0MPa (static pressure)
- 2. The temperature for water supply is 4~90°C. It is suggested to use the temperature of 60±5°C. Do not use steam to supply hot water.
- 3. The ambient temperature for use is above 0° C. If the ambient temperature is lower than 0°C, the faucet will deform and crack from freezing.
- 4. Being out of use for a long time may result in internal and external rust to the faucet and being unable to be used.
- 5. If you want to scrap this product, do not treat it as you do for general household garbage. Please follow relevant statutes to have it treated, recovered and collected appropriately by an independent recovery system.
- 6. The product in these instructions has a cleaning function.

Attentions in using

Warning: it means that ignoring this mark and misoperation may cause serious personal injury and death.

Attention: it means that ignoring this mark and misoperation may cause personal injury or property loss.

- 1. Children are not allowed to use or can use only under the custody of adult. Such special groups as the aged and disabled should be accompanied by those wife behavioral competence when using it.
- 2. The hot water supply side of the faucet is in a condition of high temperature. Do not allow skin to contact with the hardware surface directly. Otherwise, scalding may occur.
- 3.Do not reverse cold*hot water pipes. Otherwise, scalding may occur.
- 4.Do not use steam to supply hot water. Otherwise, scalding may occur.
 5.If a customer fails to use the self-contained water inlet filter net of our water
- faucet, there is such a risk as water leakage or damage due to foreign matters entering into the spool.

Attentions in use and maintenance


Attentions

- 1. As the ceramic cartridge is a precise component, do not dismantle it without authorization. Otherwise, such poor conditions as water leakage, etc. may be caused.
- 2. Do not impact the product. Otherwise, failure, water leakage may occur.
- 3. It is imperative to use a neutral detergent cleaning. Other detergents than a neutral one may damage the plating coat or make the surface discolor.
- 4. Do not use any such detergent as acidic detergent and abstergent, polishing powder, etc containing thick particles and nylon brush. Otherwise, the plating coat may be damaged etc.
- 5. It is allowed to use a piece of soft cloth to wipe or use from time to time a piece of cloth immersed in machine oil or vehicle wax to wipe. However, do not contact with resin components. Otherwise, they may lose the gloss and become rusty.
- 6. It is suggested not to leave it unused for a long time. Otherwise, this may lead to internal and external rust to faucets to such a degree that it cannot be used any more, etc.
- 7. If water pressure disgorges a large pressure please adjust the water stop valve to attain the required flow to avoid water flow being too high to splash out from the face wash basin.
- 8. With the product design being updated constantly, the physical object may not coincide with the figure. However, the basic principle for installation, use is the same.
- 9. As the manual of instructions is for common use, the existing product models may not appear therein. However, the principle for installation use is the same.

Maintenance

- To maintain a beautiful appearance of the product, the user is requested to conduct maintenance and care in the following method.
- 1. Wipe with a piece of soft cloth frequently and use a piece of soft cloth dipped in water to wipe from time to time.
- 2. When dirt exists obviously, please use water to wash sufficiently after wiping wife a neutral detergent.

Product schematic digram




Dismantle and inspection

DL367

different examples.

Phenomenon	Inspecting items
Water flow is small	6、8、9
Water leakage	2、3、4、5、10、11
Handle shakes	1, 2
Body shakes	7

Once there is any failure after instullation remove auording to the following main points (In case of removing any of the spare parts and components not removed in this diagram, please contact with relevant service staff for removal)






Dismantle and inspection

DL368


Phenomenon	Inspecting items
Water flow is small	7、11、12
Water leakage	2、3、4、5、6、10、13
Handle shakes	1, 2
Body shakes	9


Once there is any failure after instullation remove auording to the following main points (In case of removing any of the spare parts and components not removed in this diagram, please contact with relevant service staff for removal)



Dismantle and inspection

Handle disassembly key points for different examples





⚠ Attentions:Product disassembly and inspection principle is basically the same for different examples.

Product Warranty Card

User	
Sales shop or installation shop	
Buying date	
Warranty period	The warranty period for the body and valve core is 5 years and the warranty period for the remaining components is 1 year.

* If the contents in the above column are not recorded completely, the warranty will be deemed as invalid. Therefore, the users are requested to confirm the recorded contents when purchasing.

* The warranty items in this warranty are limited to repair to the free repair

items as restricted in it.

* If any failure (water leakage, release) occurs to the product during the warranty period, the users are requested to show the warranty and purchase invoice to the sales shop or installation shop and make repair requirements.

Free Repair Regulations

1. In the circumstance that the users use correctly the product of our company according to the instructions on the instruction book, sticker, etc. during the warranty period, the company will provide free repair to any faulty product.

2. When any free repair is required due to any damage during the warranty period, please hold this warranty and purchase invoice to entrust the

installation shop or sales shop for handling.

3. The repairs listed below are paid repairs during the warranty period. ① Any failure and damage resulting from improper use or unauthorized

improper repair and modification.

② Any failure and damage due to failure to pay attention or mistake in installation construction.

3 Any failure and damage due to removal for relocation, etc. after installation.
 4 Any failure and damage due to use of this product under such occasions

as being beyond the range of use (for example, commodity for home use serves as commodity for business use.)

5 Any damage resulting from sand or dirt, etc.

(6) Any poor condition such as dirty, plating rust, etc. due to improper daily

mainténance and care.

(1) Any failure and damage due to fire, earthquake, flood, lightning strike and other act of God, public nuisance, gas nuisance (liquefied gas), salt nuisance and abnormal voltage, use of other power sources than that designated (voltage, frequency), etc.

8 Other occasions not indicated in this warranty.

(9) The occasions where user name, sales shop, installation shop and purchase date are not filled out in this warranty.

① The occasion where no purchase invoice can be shown.

4. This warranty only applies to China.5. This warranty will not be reissued in case of loss. Customers are requested to preserve it properly. preserve it properly.

Conformity Certificate

This product is judged as satisfactory in inspection.

Applicable standard: GB 18145-2014 GB 25501-2010 Product Model Number: See the label on the packing box

Product name: See the label on the packing box Production date: See the label on the packing box

Assembly factory: TOTO (Dalian) Co., Ltd.

Telephone: (0411) 87624383

Factory address: 17 Dong Bei Second Street, Economic & Technical Development

Zone.Dalian

TOTO(China)Co.,Ltd.

After-sale service toll free telephone all over the country:

800-820-9787(fixed telephone)

400-820-9787(for mobile phone users)

Vendor:TOTO(China)Co.,Ltd.

Address: Room 1915, North Building of Beijing Jiali Center, No.1,

Guanghua Road, Chaoyang District, Beijing

Website:www.toto.com.cn